

Saleen Series 6 and 6.5 JB Performance Supercharger Oil installation instructions:

If this is a new or rebuilt installation, skip steps 2 and 3. Please note that it is easier to fill the supercharger oil before installation on the vehicle.

1. Locate drain plug on lower left hand side of drive snout. Clean any debris from around drain plug with a rag. Remove drain plug using 5/16 allen wrench. Use of the incorrect tool will strip out the drain plug. Inspect the o-ring around the drain plug.
2. Using provided syringe, insert the hose towards the left side of drain plug hole. Push through narrow opening about 1" (24mm). Extract oil 2 ounces at a time till no more oil can be removed. It is impossible to extract all supercharger oil due to the design of the case.
3. Clean syringe for use in installation of new JB Performance Supercharger oil. Note: Dispose of used oil at your local used oil collection facility.
4. Shake JB Performance Supercharger oil before use.
5. Fill syringe with supercharger oil and carefully extract into drain plug hole. Repeat as necessary. Fill to the bottom of the flat, machined portion inside of drain plug hole. Dry capacity is 7 ounces. If completing an oil change, capacity may be slightly less. Do not over or under fill with supercharger oil. Failure to follow these directions can result in shortened lifespan of supercharger. See picture below for reference.
6. Install new drain plug and tighten to 36 to 48 inch pounds.

Maintenance interval: 36,000 miles (58,000km)



Last update: 4/13/16