

Professional installation of this pulley is recommended.

This pulley *MUST* be completely disassembled prior to installation. Thread pulley hub by hand on shaft until fully seated before applying tightening torque (40 ft/lbs) or threads may gall. Use blue threadlocker on all (7) pulley bolts.

Ring Bolts: 3/16" Pulley Cover Bolt: 5/32"